





# Photographic Accessory Chart



# Optional Accessories for Imaging



## Camera Adapters / T-rings

**39361**  
**Eyepiece Projection Camera Adapter**  
Weight: 242 g (8.54 oz)  
• For eyepiece projection photography  
• 105mm in length and 60mm in diameter  
• Attachable to flip mirror or R200SS focuser  
• Not usable with LVW series eyepiece and 50.8mm eyepiece.

**3911**  
**Camera Adapter 36.4**  
Weight: 196 g (6.91 oz)

**3523**  
**Camera Adapter 43 DX**  
Weight: 390 g (13.76 oz)  
• For both prime focus and eyepiece projection photography.  
• Attachable to 43mm thread  
• With 48mm thread for filter  
• 164mm in length and 63mm in diameter  
• Not usable with 50.8mm eyepiece.

**3876**  
**Wide Photo Adapter 60mm for Canon EOS**  
Weight: 55 g (1.94 oz)  
• For prime focus photography with R200SS or VC200L  
• Use a T-ring together.

**3877**  
**Wide Photo Adapter 60mm for Olympus**

**3878**  
**Wide Photo Adapter 60mm for General type**

**3763**  
**T-C Ring**  
Weight: 52 g (1.83 oz)  
• For C-mount

**Please specify your camera brand in the ordering.**

Code	T-Ring for	Applicable SLR Camera Models	Weight
3764	Nikon, Fuji Film	Nikomart(EL, EL2, FT, FT2, FT3), EM, FA, FE, FE2, FE10, FG, FG-20, FM, NewFM2, NewFM2T, FM3A, FM10, F2, F2 Photomic, F2 Photomic (A, AS, SB), F3, F3AF, F3T, F4, F4S, F4E, F5, F6, F80, F90D, F90S, F90X, F90XD, F90XS, F90D Panorama, F70D Panorama, F301, F401, F401X, F601, F601M, F801, F801S, Prouna600i, F100, F80, U, U2, Digital Camera(D1X, D1H, D1, D2H, D2Hs, D2X, D2XS, D70, D100, D200, D70S, D50, D80, D40, D40X), Fuji film, Digital camera (S1Pro, S2Pro, S3Pro, S5Pro)	22g (0.78 oz)
3765	Canon	A-1, AE-1, AE-1 Program, AL-1, AV-1, EF, F-1, NewF-1, FT, FTb, T50, T70, T80, T90	40g (1.41 oz)
3766	Minolta	SR101, SRT Super 101, SR505, X-1, X-7, X-70, X-500, X-600, X-700, XD, XD-S, XE, XG-E, XG-S	30g (1.06 oz)
3769	Vixen, Pentax K, Ricoh, Cosina	Vixen(VX-1, VX-2), Pentax(Super A, AE-F, A3DATE, K2, KX, KM, LX, ME, ME Super, ME-F, MG, MX, MV-1, MZ-3, MZ-5, MZ-10, MZ-50, MZ-M, P30N, P30T, P50, SF7, SFXN, SFXW, Z-1, Z-1P, Z-5, Z-10, Z-20, Z-20P, Z-50P, Z-70P, Z-mate), Digital camera (*istDs2, *istD, *istDL, K100D, K100D), Ricoh(XP-P, XR-1, XR-2, XR-3, XR-7, XR-7MIII, XR-8, XR-8SUPER, XR-10M, XR-10PF, XR-20SP, XR-S, XR500Auto), Cosina (CT-1A, CT-1EX, CT-7, CT-20)	36g (1.27 oz)
3770	Konica	FC-1, FT-1, FTA, New FTA, FS-1, T3, New T3, TC-X, ACOM-1	46g (1.62 oz)
3771	Contax	AX, Aria, AriaD, Yashica108, YashicaFR-1, YashicaFR-2, YashicaFX-3, YashicaFX-3 Super2000, YashicaFX-D Quartz, RTS, RTSII, RTSIII, RX, S2, S2b, ST, 137MA Quartz, 137MD Quartz, 139 Quartz, 159MMRTS II Quartz, 167MT	34g (1.20 oz)
3768	Practica (Screw mount)	Pentax (ES, ES-II, SP-II, SPF), Yashica (ElectroX, FFT, TTS), Fujica(ST605, ST701, ST801, ST901), Mamiya (Secor 500D, 1000D, 1000DTL, MSX500), Ricoh(TL-S, TLS401), Petri (MF-1), Practica(LLC)	25g (0.88 oz)
3760	Sony (Konica Minolta)	α3xi, α5xi, α7xi, α7, α9xi, α-Sweet, α101si, α303si, α303siSUPER, α507si, α707si, α807si, α3700i, α5000, α5700i, α7000, α7700, α8700i, α9000, Digital camera (RD-175, α-7DIGITAL, αSweetDIGITAL), SONY α100	45g (1.59 oz)
3742	Yashica AF	Kyosera (200-AF, 210-AF, 230-AF, 270-AF, 300-AF)	42g (1.48 oz)
3776	Canon EOS	EOS(1, 1HS, 1N, 1NDR, 1NHS, 1NRS, 50D, 100D, 55, 100 Panorama, 100QD, 620, 630QD, 650, 700QD, 850, 1000QD(panorama), 1000SQD(kitII, kitIII), RT, IXE, IX50), EOS Kiss, NEW EOS Kiss, EOS Kiss III L, EOS Kiss 5, EOS Kiss Lite, EOS Kiss 7, EOS-IV, EOS-IVHS, EOS-3, EOS-7, EOS-7S, Digital camera (EOS-DCS1c, EOS-DCS3c, EOS-1D, EOS-1Ds, EOS-1Ds MarkII, EOS-1D MarkII, EOS-1D MarkIII, EOS-1D MarkIII N, EOS-5D, EOS-50D, EOS-20D, EOS-20Da, EOS-30D, EOS-D60, EOS-D30, EOS Kiss Digital, EOS Kiss Digital N, EOS Kiss Digital X)	52g (1.83 oz)
3763	C-Mount	Video Camcorder for C mount	52g (1.83 oz)
3773	Four Thirds	Digital camera (Olympus E-1, E-300, E-330, E-410, E-500, E-510), (Panasonic DMCL1K)	30g (1.06 oz)